

CU 2500 + CU 2500 basic

POS.	PART NO.	DESCRIPTION
1	30216	Insert plate w/bolt f/drum, right
2	30217	Insert plate w/bolt f/drum, left
3	30222	Adjusting bracket drum
4	30222	Adjusting bracket drum
5	30221	Adjusting bracket motor, left
8	30220	Adjusting bracket motor, right
7	30219	Insert plate w/bolt f/motor, left
6	30218	Insert plate w/bolt f/motor, right
15	31024	Left side profile 2500
16	31020	Right side profile 2500
10	31010	PVC belt 2500
11	31009	Bottom plate 2298mm with holes
12	31043	Top profile stainless steel 2.5 m
13	31014	PVC side protection, 1 m
19	30246	Insert left for unit box 145 mm
9	30215	Belt guide complete (set) - CU/CCU
25	31060	Connection piece
17	31051	Drum
18	31052	Motor CU/CCU incl plug
14	30245	Insert right for unit box 80 mm

POS.	PART NO.	DESCRIPTION
	50340	Rubberwheel (1 pc) for undercarriage
	30213	Catch for undercarriage and for hopper
20	31081	CU unit 240V basic
20	31085	CU unit 110V basic
20	31080	CU unit 240V
20	31084	CU unit 110V
	32204	CU unit 240V basic - renovated
	32205	CU unit 110V basic - renovated
	32200	CU unit 240V - renovated
	32202	CU unit 110V - renovated
	30229	Emergency stop, complete
	30232	Changeover forwards/backwards switch
	30234	Potentiometer/speed controle, complete
	30227	CU/CCU plug IN
	30228	CU/CCU plug OUT
	30235	Miniature fuse 63mA for CU/CCU unit
	30250	Frictionband for engine
	30053	CU/CCU connection cable, 7 m
	50105	Adapter cable 240V 10A w/CEE and Schuko plug

