

CXL 6000

POS.	PART NO.	DESCRIPTION
1	30216	Insert plate w/bolt f/drum, right
2	30217	Insert plate w/bolt f/drum, left
3	30222	Adjusting bracket drum, right
4	30223	Adjusting bracket drum, left
5	30212	Nylon guides (set of 5 pcs)
6	30211	Scrubber, complete
8	30207	PVC cover at scrubber, set
9	30219	Insert plate w/bolt f/motor, left
10	30218	Insert plate w/bolt f/motor, right
11	30225	Adjusting bracket motor, left
12	30224	Adjusting bracket motor, right
13	30210	E-stop complete white CXL - inside mounting
	30209	E-stop complete yellow CXL - outside mounting
14	30201	Main switch 16µF 240V
15	30205	Inlet socket, complete
16	30243	Motor 0.5kW 1x240V, Ruimeca
17	31051	Drum
19	31008	Bottom plate 2135 mm with holes
19.1	31002	Bottom plate 1900 mm
19.2	31001	Bottom plate 1710 mm
20	31043	Top profile 2500 mm
20.1	31040	Top profile 1300 mm, right
20.1	31041	Top profile 1300 mm, left
21	31014	PVC side protection, 1 m
22	30214	Belt guide, complete
23	30249	Inlet plate, set
24	31060	Connection piece
25	31027	Left side profile CXL 6000
26	31023	Right side profile CXL 6000

POS.	PART NO.	DESCRIPTION
	32003	PVC belt 6000, no cleats
	31013	PVC belt 6000
	32007	PVC belt 6000 20 mm, cleats
	32011	PVC belt 6000 40 mm, cleats
	32015	PVC belt 6000 60 mm, cleats
	32019	PVC belt 6000 20 mm, V-chevron cleats
	32023	PVC belt 6000 60 mm, wavy edge cleats
	30247	Start/stop button incl rubber protection
	50320	Rubber protection for start/stop button
	30204	Starting capacitor 40µF
	30202	Working capacitor 16µF, Ruimeca
	50340	Rubberwheel (1 pc) for undercarriage
	30213	Catch for undercarriage and for hopper
	30250	Frictionband for engine
	50105	Adapter cable 240V 10A w/CEE and Schuko plug

